PROFoil
Interactive Touch Film

TOUCH FOIL UNPACKING
I N S T R U C T I O N S

Overview

Congratulations on purchasing your very own touch foil! To ensure that your installation goes as smoothly as possible, this document will instruct you on how to properly unpack your touch foil.

The following items will be enclosed in the PROFoil shipping container for your touch foil:

- Touch foil
- Electronic control board (PCB board)
- Micro-USB connector cable
- Cling film
- Assorted packing materials

If at any point you are unsure of how to proceed, or believe that a component was not sent to you, please contact us immediately for additional assistance.

Unpacking the Foil:

When you receive your touch foil, it will arrive in a tube very similar to what is shown below. The tube is sent using mirrored packing material, which means you **do not** have to begin unpacking it from a specific side of the container.

For the purpose of these instructions, we will be unpacking from the right side of the tube. On each side of the packing tube, there will be a cap held in place by industrial tape.

Simply remove the tape to open the tube's holding cap.

Once the cap has been removed, you will have access to the foam protectors on either side of your foil. Each foam protector is used to provide additional insulation for your touch foil, while also keeping any loose components inside the inner tube. Carefully extract your touch foil materials from the packing tube by using the foam protector as a handhold.

Be careful not to remove the foam protector until the inner tube has been completely pulled out. This is to make sure the loose components inside have no risk of being dropped accidentally.

As soon as the inner tube has been extracted, you may remove the foam protector. You should be able to see all of your components safely contained inside the inner tube.

The small brown envelope contains your touch foil's PCB board, while the small plastic bag contains the micro-USB connector cable. On the outside of the inner tube, you will see your white cling film wrapped over foam paper.

Underneath the foam paper, you will find your touch foil. At this point, you can freely unwrap the different components until they are laid out as seen below.

*Note: **DO NOT** attempt to cut any labels or tape that have been placed over your cling film and touch foil. Any accidental incisions on the touch foil will prevent the item from working as expected and void your warranty. Carefully peel the labels and/or tape away to unpack these items.

CONGRATULATIONS!

Now that your materials have been successfully unpacked, you are ready to table-test and install your PROFoil! To properly install your touch foil, download our Touch Foil Installation Manual for additional instructions at:

http://www.profoils.com/support/

PROFoil - Interactive Touch Film

269 Technology Way, Suite 1
Rocklin, CA 95765

(888) 631-5880

info@touchfoil.us